



Technology for Licence

Porous Glass Microspheres

A tailored, single-stage and scalable manufacturing process

In brief

Porous glass microspheres (MS) are produced via a novel flame spheroidisation process, enabling precise tailoring of MS porosity, size, chemistry and other variables to address a wide range of potential applications.

Compared to other manufacturing techniques, this single-stage process is: efficient, less time-consuming and energy intensive, scalable, and offers better control over pore size, interconnected porosity and morphology.

Background

Microspheres exhibit greater advantages over irregular-shaped particles, with an improvement in flow properties and the porous or hollow structure. Porous microspheres can be loaded with active or functional entities. They have a relatively large surface area and allow for the encapsulation of components, leading to a wide range of uses, from adhesive additives to drug delivery or energy storage.

Key features

This technology is a novel flame spheroidisation process to manufacture highly porous glass microspheres.

Key features are:

- Particles produced are of spherical morphology
- The production technique is eminently scalable with the current lab-scale production method at 1–3 kg/h.
- Facile production process amenable to be transferred to GMP standards




Fig 1: Schematic representation of the proposed mechanism for manufacturing porous glass microspheres via the flame spheroidisation process.

A single-stage, reliable, reproducible and scalable method of manufacture.

Size, level of porosity, degradation rates and material can be tailored.

Produces unique spherical glass materials with a high degree porosity.

Demonstrated in bone regeneration

Research has proven the effectiveness of injectable pastes of porous calcium phosphate glass microspheres in tissue engineering and bone regeneration. Glass microsphere formulations with 40 mg/mL xanthan gum displayed optimal flow characteristics and were readily injectable via a syringeneedle system (3–20 mL, 18G and 14G needles), proving their potential as a cell (or other biologics) delivery vehicle.

Tailorable properties

- Size: ranging from 60–350 microns diameter
- Level of porosity: from <5% up to >80%
- Degradation rates: can be controlled from days, weeks up to months
- Base material: phosphates, silicates, borates and glass ceramics – the main types of bioactive glasses

Applications in engineering, biotechnology and healthcare

Applications for this novel fabrication process have been identified in: medical devices, bone regeneration, resorbable implants, separation science, osteoplasty, bone surgery, joint surgery, hip revisions, spine surgery, spinal fusion, osteoconductivity, orthopaedic surgery, dentistry, bone fixation, filtration and fillers.

We are interested in licensing or collaborations related to potential areas of application. Small samples for assessment can be supplied by agreement.

IΡ

Patent protected WO2016027110 EP3183224

Enquiries

Peter McLeod Licensing Executive peter.mcleod@nottingham.ac.uk +44 (0)11574 85507